


Parts List: OT300-500*2: Tank

For units with serial numbers beginning with 2308 and above



#	Description	Part #
1	Control Panel Cover	17111
2	Knob	19867
3	Flame Rod (w/ gasket)	19853R
4	Hot Surface Igniter (w/ gasket)	19945R
5	Air Intake Assembly	19978
6	Insulation (Tank Top)	18153
7	Powered Anode Rod, 16"	15152
8	Cover Plate (Trans-Chamber 2)	17126
9	Sensor, Second Pass	21599

#	Description	Part #
10	Drain Valve	15590
11	Baffle	16604
12	Tank Temp Sensors (2-in1)	21594
13	Plug, 1", Square head	15297
14	T&P Relief Valve	21785
15	Outlet Pipe Nipple	15407
16	Inlet Pipe Nipple	15340
17	Powered Anode Rod, 20"	15153
18	Gasket, Burner Mount Plate	18216

#	Description	Part #
19	Flue Gas Temp Sensor	21596
20	Trim Plate (2 pcs.)	19419
21	Condensate Elbow Assembly	19986
22	Hand Hole Access Cover	17190
23	Hand Hole Gasket	27015
24	Hand Hole Cover Plate	27030
25	Burner Refractory	18006