



| # | DESCRIPTION                     |        |
|---|---------------------------------|--------|
| 1 | Control Panel Cover             | 17125  |
| 2 | Knob                            | 19867  |
| 3 | Sight Glass, 1/4" NPT           | 21819  |
| 4 | Flame Rod (w/ Gasket)           | 19852R |
| 5 | Hot Surface Igniter (w/ Gasket) | 19948R |
| 6 | Air Intake Assembly             | 19979  |
| 7 | Insulation, Tank Top            | 18228  |
| 8 | Powered Anode Rod, 43"          | 15150  |
| 9 | Powered Anode Rod, 16"          | 15152  |

| #  | DESCRIPTION               |       |
|----|---------------------------|-------|
| 10 | 2nd Pass Sensor           | 21599 |
| 11 | Switch, Blocked Intake    | 20012 |
| 12 | Power Supply Junction Box | 21640 |
| 13 | Baffle                    | 16604 |
| 14 | Inlet/Outlet Pipe Nipple  | 15315 |
| 15 | Tank Temperature Sensor   | 21594 |
| 16 | T&P Relief Valve          | 21790 |
| 17 | Condensate Trap Assembly  | 19985 |
| 18 | Trim Plate                | 19418 |

| #  | DESCRIPTION                   |       |
|----|-------------------------------|-------|
| 19 | Exhaust Temperature Sensor    | 21596 |
| 20 | Switch, Blocked Exhaust, NC   | 20014 |
| 21 | Hand Hole Gasket              | 27015 |
| 22 | Hand Hole Cover Plate         | 27030 |
| 23 | Hand Hole Access Cover        | 17190 |
| 24 | Drain Valve                   | 15590 |
| 25 | Plug, 1", Square head         | 15297 |
| 26 | L Bracket (for switch)        | 20107 |
| 27 | Screw, L Bracket (for switch) | 20111 |