



#	DESCRIPTION	
1	Control Panel Cover	17125
2	Knob	19867
3	Sight Glass, 1/4" NPT	21819
4	Flame Rod (w/ Gasket)	19852R
5	Hot Surface Igniter (w/ Gasket)	19948R
6	Air Intake Assembly	19979
7	Insulation, Tank Top	18228
8	Powered Anode Rod, 43"	15150
9	Powered Anode Rod, 16"	15152

#	DESCRIPTION	
10	2nd Pass Sensor	21599
11	Switch, Blocked Intake	20012
12	Power Supply Junction Box	21640
13	Baffle	16604
14	Inlet/Outlet Pipe Nipple	15315
15	Tank Temperature Sensor	21594
16	T&P Relief Valve	21790
17	Condensate Trap Assembly	19985
18	Trim Plate	19418

#	DESCRIPTION	
19	Exhaust Temperature Sensor	21596
20	Switch, Blocked Exhaust, NC	20014
21	Hand Hole Gasket	27015
22	Hand Hole Cover Plate	27030
23	Hand Hole Access Cover	17190
24	Drain Valve	15590
25	Plug, 1", Square head	15297
26	L Bracket (for switch)	20107
27	Screw, L Bracket (for switch)	20111